

**Traditional Underpinning**

Traditional underpinning techniques are used to increase the effective depth of an existing foundation that has been affected by clay heave, erosion or other subsoil movement. Underpin bays (approx.1200mm long) are constructed to a pre-determined sequence to protect the integrity of the existing structure. The works can be carried out internally or externally depending on specific requirements.

